


BLADE

POWERSPORTS.COM

To loosen or tighten the chain on the Blade 250XT series is fairly easy. For ease, you may wish to remove the rear wheel on the side in which you are adjusting, but many find that the adjustment can be made with the tire in place.



The brass colored tool as pictured below is for the chain adjustment. To adjust your chain, simply jack up your Buggy off of the floor, and please keep in mind that with the rear wheels up, the Buggy will roll, so please block the front wheels. Now loosen the 6 allen head bolts from the rear of the swing arm.

With the tool placed in the holes on the hub, you turn the tool toward the front of the Buggy to loosen the chain and toward the rear to tighten. After you have achieved the

proper chain tension (1/4 to 3/8" play) you simply tighten the 6 allen heads and lower the buggy and away you go!

